



## **Anti Slip Tape Installation Instructions**

### **1) Material Storage**

Store the tape in a dry, warm environment inside its original protective packaging until ready for use.

### **2) Surface Preparation**

Ensure the surface is clean, dry, and free from dust, paint flakes, or grease.

- Use an IPA (isopropyl alcohol) cleaner for best results.
- Do not use methylated spirits, petrol, or lighter fluid as these leave a greasy residue.
- Application should be done when the surface temperature is above 10°C.

### **3) Porous Surface Sealing**

Porous surfaces such as wood, concrete, or stone must be sealed before application to prevent water ingress, which can degrade the adhesive.

- A toluene-based primer is ideal.
- Apply a thin coat with a paintbrush and allow to dry fully before proceeding.

### **4) Tape Application**

- Begin by peeling back a small section of the release liner and firmly pressing the adhesive side onto the prepared surface.
- Continue to peel and stick the tape gradually, avoiding tension in the material.
- Avoid stretching the tape during application.

### **5) Finishing Touch**

- After placement, press the tape down firmly with even pressure using a roller (e.g., a decorating roller).
- For best durability, apply an edge sealing compound to the sides of the tape using a thin bead.
- The tape can be walked on immediately, but full adhesive strength is achieved after 48 hours.

### **Support**

For additional installation support, please contact your supplier.