



## **Rubber Corner Guard Installation Instructions**

1. Cut the rubber corner guard to the desired length.
2. Select a No.12 screw suitable for the substrate. Drill 7mm diameter holes in the corner guard.

Note: When drilling, stagger the hole positions. Start 15mm from the top on one wing, and 25mm from the top on the other.

Space the remaining holes evenly over the length of the corner guard.

3. Use the corner guard as a template to mark hole positions on the wall. Drill using a bit suited to the wall fixings.
4. Attach the corner guard to the wall using flat washers and appropriate fasteners.