



## **Skirting Installation Guidelines**

### **Aluminium & Stainless Steel Skirting**

Please read the following instructions prior to installation:

1. Ensure the substrate is dry, smooth and free from contaminants. Where a substrate is dusty it may be necessary to prime with a suitable primer.
2. Remove any protective film from the surface of the skirting.
3. Measure and cut the skirting to the required length using a proprietary blade for the material and cutting tool used.
4. Apply suitable cartridge adhesive to the back of the skirting. Offer the profile to the wall and apply even pressure along the entire length to ensure full contact of the adhesive with the skirting.
6. To provide a neat finish to cut ends, a range of aluminium accessories are available to order.