



Wall Protection – Installation Instructions

Textured Corner Guards (Tape-on / Adhesive Fix)

1. Textured Corner Guards must be installed in environmentally controlled conditions and allowed to acclimatise to room temperature for 24 hours. Ideal temperature is 16°C–18°C.
2. Inspect the substrate: it must be flat, sound, clean, and free from contaminants (oil, dust, etc.). Prime if needed. Wallpaper behind the guard should be removed and substrate repaired before installation.
3. Measure and cut guards to size before installation using a circular or hand saw. Deburr ends with a fine file.
4. For tape-on guards: peel off tape cover, align bottom, then apply upward with full contact and firm pressure. Use a rubber roller or soft-covered block.
5. For porous or difficult substrates, order guards without tape (suffix 'N'). Clean and prepare substrate per step 2.
6. For adhesive install (no tape), use construction adhesive. Apply 5mm beads of adhesive 10mm from each edge using a gun and nozzle cut to proper width.
7. Press guard firmly across its surface to bond. Use roller or soft-covered block to assist.
8. When installing multiple guards, ensure horizontal alignment using a laser or spirit level.